



opticalCON

RETROFITTING NEW OPTICALCON LOCKING CAP

The procedure for retrofitting the new opticalCON ADVANCED locking cap to first generation opticalCON connectors is quite straightforward.

Unscrew the connector front housing.

Remove the 'O' ring from the exposed threaded section of the connector body, leaving the spring in place.

The cap ring holding the lanyard is in two parts, slide these one at a time towards the spring until they clip together.

Replace the rubber 'O' ring and screw the connector front housing back on to the connector body taking care to observe the correct keyway alignment.

The old rubber cap and lanyard (rubberised coil) should be cut off.